










# Fiery PRO<sup>80</sup> 80C-KM Image Controller

## Accessory parts

### I. Accessory parts

No.	Name	Shape	Q'ty
1.	FieryPRO <sup>80</sup> 80C-KM	 A039IXC001CA	1
2.	Power cord (U.S.A. / UK Europe / Australia)	 A039IXC002SA	each 1
3.	VI cable	 A21DIXC021CA	1
4.	Media Pack	 A21DIXC021CA	1
5.	Installation manual		1
6.	Accessory parts guide		1
7.	Screw	 A039IXC002CA	2
8.	PATCH CD		1
9.	Other documents		1 set
<ul style="list-style-type: none"> <li>• READ ME WEEE STATEMENT</li> <li>• END USER LICENSE</li> <li>• Fiery SETUP ROADMAP</li> <li>• READ ME FOR DISPOSAL BATTERIES</li> <li>• READ ME EUROPEAN BATTERIES</li> <li>• READ ME C8000 PERSONALIZATION</li> <li>• READ ME LINE SCREENS</li> <li>• READ ME INSTALLATION STEPS</li> </ul>			




### Note:

The screws of No. 7 are not used for the controller setup.

They are the replacement when the connector screw on the side to which the VI cable is connected (main body/controller) is bad. Keep them at hand.

### UK-102/PERSONALIZATION KIT

(C8000 only)

No.	Name	Shape	Q'ty
1.	Fiery Option Utility CD		1 set
2.	Dongle	 A21DIXC001CA	1
3.	Dongle user manual		1