



[1] Pressure roller /FrRt	[2] Drive gear of the humidification roller pressure motor /Rt (M9) shaft
[3] Drive gear of the humidification roller pressure motor /Lt (M10) shaft	[4] Pressure roller /FrLt
[5] Humidification roller pressure home sensor /Rt (PS9)	[6] Humidification roller pressure home sensor /Lt (PS10)
[7] Water feed roller /Lt	[8] Humidification roller /Lt
[9] Humidification roller /Rt	[10] Water feed roller /Rt
[11] Humidification pressure cam /FrLt	[12] Humidification pressure cam /FrRt